
SERVICE MANUAL

# TT493

4822 725 50891



Downloaded from www.linephaze.com

#### **MARANTZ DESIGN AND SERVICE**

Using superior design and selected high grade components, MARANTZ company has created the ultimate in stereo sound.

Only original MARANTZ parts can insure that your MARANTZ product will continue to perform to the specifications for which it is famous.

Parts for your MARANTZ equipment are generally available to our National Marantz Subsidiary or Agent.

#### **ORDERING PARTS:**

Parts can be ordered either by mail or by telex. In both cases, correct part number has to be specified. The following information must be supplied to eliminate delays in processing your order:

- 1. Complete address
- 2. Complete part numbers and quantities required
- 3. Description of parts
- 4. Model number for which part is required
- 5. Way of shipment
- 6. Signature: any order form or telex must be signed otherwise such part order will be considered as null and void.

MARANTZ INTERNATIONAL

Vestdiik 9

5600 MD Eindhoven The Netherlands

Phone: +31/40.758290 Telefax: +31/40.75.82.99

Telex: 35000 PHTC NL routing IND NLMTFAT

#### PARTS ORDERING

Parts may be ordered at the following addresses:

**AUSTRIA** HORNYPHON Vertriebsgesellschaft GmbH Wienerbergstrasse 1

Austria Telex: 132.332

SVD DIVISION MARANTZ

Industrialaan 1 1720 Groot-Bijgaarden Belgium

Telex: 24466

CHILE MARANTZ DIVISION OF PHILIPS S.A. AV. Santa Maria, 0760 Casilla 2687

Santiago Telex: 240.239

DENMARK DIVISION OF PHILIPS SERVICE A/S Prags Boulevard 80 Postbox 1919 DK-2300 København S

Denmark Telex: 31201

**FINLAND** MARANTZ DIVISION OF OY PHILIPS Ab Kaivokatu 8 00100 Helsinki

Finland

Telex: 124811

MARANTZ FRANCE 4 Rue Bernard Palissy 92600 Asnières France Telex: 611651

**GERMANY** MARANTZ GERMANY GmbH Max-Planck-Strasse 22 6072 Dreieich 1

Germany Telex: 529821

THE NETHERLANDS Elpro Marantz Wint Hontlaan 28

3526 KV Utrecht The Netherlands Telex: 4748

NORWAY

MARANTZ DIVISION OF PHILIPS A/S Sandstuveien 40 0680 Oslo 6

Norway Telex: 72640 GREAT BRITAIN

MARANTZ AUDIO U.K. Ltd Unit 15/16 Saxon Way Industrial Estate Moor Lane Harmondsworth UB7 OLW

Great Britain Telex: 935196

GREECE

SHERTON ELECTRONICS S.A. P.O.Box 21025 Hippocratus Street 188 Athens 11471

Greece Telex: 216.795

**JAPAN** 

MARANTZ JAPAN, Inc. 35-1, 7-chome, Sagamiono Sagamihara-shi, Kanagawa

Japan

**KUWAIT** AL ALAMIAH ELECTRONICS Ussama Building Fahd al Saleem Street

P.O.Box 23781 Safat-Kuwait Telex: 22694

MARANTZ ITALIANA S.P.A. Via Chiese, 74 20126 Milano

Italy

SAUDI ARABIA

AL ALAMIAH ELECTRONICS P.O.Box 5954 University Street Riyadh 11432 Saudi Arabia Telex: 401530

SOUTH AFRICA MARANTZ DIVISION OF PHILIPS S.A. Main Road Martindale P.O. Box. 58088 Newville 21114 South Africa

SPAIN

PHONO S.A. Ignacio Iglesias 10 Badalona (Barcelona) Spain

Telex: 59355

Telex: 14060

**SWEDEN** 

MARANTZ DIVISION OF PHILIPS Försäljning AB Tegeluddsvägen 1 S-115 84 Stockholm Sweden

SWITZERLAND

DYNAVOX ELECTRONICS Route de Villars 105 1701 Fribourg Switzerland Telex: 942377

TURKEY

DOGRUOL Ltd. I.M.C. 6 Blok N°6310 Unkapani Istanbul Turkey Telex: 22085

**CACHIA & GALEA** Republic Street, 68D Valetta Telex: 1682

Telex: 43906

PORTUGAĹ MARANTZ Divisao philips S.A. service Outurela-carnaxide 2795 LinDA-A-VELHA

All of the above locations are fully equipped to take care of your total service needs. Because various countries have differing configuration requirements, it is necessary that you contact the service facility in your particular country. In the event that there is no service location listed for your country, please, contact the nearest facility for the necessary assistance.

> In case of difficulties, do not hesitate to contact the Technical Department at abovementioned address.

Downloaded from www.linephaze.com

# SPECIFICATIONS (Limit)

**TURNTABLE** 

Motor

DC Servo motor

Speed

33-1/3 and 45 r.p.m.

Wow & Flutter Rumble

 $\pm$  0.15 % (WRMS)

Turntable platter

57 dB DIN-B 296 mm aluminum alloy die-cast

**TONEARM** 

Effective length Usable cartridge

**CARTRIDGE** 

Type

CT493

195 mm

**OPERATION** 

Output voltage

Channel balance

Load resistance

Channel separation

Automatic return,

Within 3 dB at 1kHz

More than 16 dB at 1kH

automatic shut off, stop

1.7~3.4mV at 1kHz 3.54 cm/sec.

Cueing

Oil-damped

47 K $\Omega$ 

0.6 mil stylus

Moving Magnet type

Frequency response 20-20,000 Hz

**GENERAL** 

Power consumption 1.5 watts

**Dimensions** 

 $360(w) \times 102(h) \times 350(d) \text{ mm}$ Weight 2.6 kg(net)

NOTE: Nominal Specs represent the design specs; all units should be able to approximate these-some will exceed and some may drop slightly below these specs. Limit Specs represent the absolute worst condition which still might be considered acceptable; in no case should a unit perform to less than within any Limit Spec.

Lubrication of the mechanism is not required. However, whenever a unit is brought in for adjustment or repair, always use good common sense ... clean any dust or dirt from mechanical parts and if moving parts do seem to bind, check for dirt. If necessary, add a very fine film of light-weight specially formulated lubricant.

Specifications and appearance are subject to change for modification without notice.

# **MODEL TT493 AUTO RETURN TURNTABLE**




# TABLE OF CONTENTS

		Page
1.	SCHEMATIC DIAGRAM	4
2.	PARTS LOCATIONS	4
3.	EXPLODED VIEW	5
4.	PARTS LIST	6
5.	ADJUSTMENTS	7
6	DISASEMBLY INSTRUCTIONS	7

MZ 2269

Downloaded from www.linephaze.com

## 1. SCHEMATIC DIAGRAM




Components and wiring are subject to change for modification without notice.

To service personnel Make sure that only replacement parts recommended by the manufacturer should be used when the parts marked "\( \int \)" in schematic diagram are exchanged.

Never fail to make leakage-current or resistance


Never fail to make leakage-current or resistance measurements before returning the appliance to the customer so as to make sure that exposed parts are acceptably insulated from the supply circuit.

# 2. PARTS LOCATIONS



MZ 2270

# 3. EXPLODED VIEW



Downloaded from www.linephaze.com

### 4. PARTS LIST

N: for Europe E: for Europe A: for Australia

REF. DESIG.	PART NO.	DESCRIPTION
1	4822 444 10152	Cabinet
2	4822 450 61477	Window, Front
3	4822 410 26568	Button, Stop
4	4822 410 26569	Button, Cue
5	4822 410 60416	Button, Speed
6	4822 535 70979	Spacer
7	4822 403 40263	Arm, Cue
8	4822 402 50256	Lever, Cue
9	4822 535 92495	Rod, Cue
10	4822 535 92496	Rod, Stop
11	4822 444 60557	Dust Cover
12	4822 462 71515	Buffer, Dust Cover
13	4822 417 11007	Hinge Ass'y
17	4822 466 61313	Cushion, Motor
18	4822 462 41492	Cushion, Bracket
20	4822 403 10274	Arm, Stop
21	4822 276 11637	Push Switch
22	4822 492 42254	Spring
23	4822 528 90687	Rec. Adaptor
24	4822 466 50206	Sheet, Turntable
25	4822 522 32296	Gear
26	4822 402 61084	Cam
27	4822 402 61085	Cam
28	4822 402 61171	Arm, Return
29	4822 402 61173	Bracket, Pick up
30	4822 402 61206	Lever Ass'y
32	4822 532 52156	Spacer, Pick up
34	4822 492 42255	Spring, Lever Ass'y
35	4822 402 61172	Arm, Lifter
36	4822 358 30758	Belt, Turntable
37	4822 535 92494	Shaft, Turntable
38	4822 251 70388	Spring, Arm Lifter
39	4822 528 10697	Turntable
40-1	4822 251 70316	Tonearm
40-2	4822 251 11019	Cartrige, CT493
40-3	4822 251 11021	Stylus, CTS493
40-4	4822 530 70532	Retainer, Stylus
SW101	4822 276 12381	DC POWER CIRCUIT BOARD Push Switch
3,1,101	7022 270 12001	
D101	4822 130 81722	Diode, MPG06B-G3
D102	4822 130 81722	Diode, MPG06B-G3
D103	4822 130 81722	Diode, MPG06B-G3
D104	4822 130 81722	Diode, MPG06B-G3
VR101	4822 100 11558	30KΩ Trimming
VR102	4822 100 11559	5KΩ Trimming
44	4822 321 23689	Connective Cord
1	1	T. Control of the Con

REF. DESIG.	PART NO.	DESCRIPTION	
<b>∆</b> 46 <b>∧</b> 46	4822 146 21472 4822 146 21468	Power Transformer Power Transformer	N, A E
47	4822 361 21101	Phono Motor	
SW01	4822 276 12379	Mini Switch	
. 1 50	4822 266 30212	Voltage Selector	E
160 212	4822 736 20445 4822 532 52155	User's Manual Washer	

To service personnel


Make sure that only replacement parts recommended by the manufacturer should be used when the parts marked "\tilde{\texts}" in schematic diagram are exchanged.

Never fail to make leakage-current or resistance measurements before returning the appliance to the customer so as to make sure that exposed parts are acceptably insulated from the supply circuit.

## 5. ADJUSTMENTS

#### (A) AUTO-RETURN

- 1. Set the Tonearm (40-1) at the cueing up position.
- 2. By turning the Screw (206), adjust the Arm (28) so that the Cam (26) is hooked by the Shaft (37) when the stylus is at the position R-61.5~62mm from the center of the Shaft (37).
- 3. Check the Tonearm (40-1) returns after music Play.



#### (B) ROTATION SPEED

- 1. Select "45" rpm by the SPEED Button (5).
- 2. Adjust speed by turning the Trimming Resistor(VR102) through the hole (A) on the Bottom Ass'y (16A).
- 3. Select "33" rpm by the SPEED Button (5).
- Adjust speed by turning Trimming Resistor (VR101) through the hole (B) on the Bottom Ass'y (16A).

NOTE: Adjust for "45" rpm first. and then "33" rpm next.




Fig. 2

#### 6. DISASSEMBLY INSTRUCTIONS

- (A) Remove the Dust Cover (11) and fix the Tonearm (40-1) to the arm rest.
- (B) Remove the Turntable Sheet (24), and the Belt (36) from the Pulley. Then remove the Turntable Platter (39).
- (C) Remove the Six Screws (202) on the Bottom Ass'y (16A), then remove the Bottom Ass'y (16A).




Fig. 3

MZ 2273

<u> — 6 —</u>

Downloaded from www.linephaze.com